

# Crystal calorimeters - improving rate capabilities

Intensity Frontier prospective



P.Murat (Fermilab)

Oct 06 2015

## Introduction



- crystal calorimeters win when required energy resolution  $\sigma_E/\sqrt{E} < 5 - 10\%$
- at very high energies:  $\sigma_E/E = a/\sqrt{E} \oplus b \oplus c/E$ , energy-dependent terms small
- with the increasing beam intensity handling of the pile-up becomes increasingly important
- focus shifts towards improving resolution between two interactions - timing
- energy frontier: maintain energy resolution
- intensity frontier: preserve 1/L sensitivity scaling
- in case background is dominated by random coincidences, single particle timing resolution also needs to improve
- **what does it take to improve the rate capabilities of the crystal calorimeters by x10?**

## Intensity Frontier experiments: crystals




- crystal calorimeters of the current and coming intensity frontier experiments: KOTO(undoped CsI), Mu2E ( $\text{BaF}_2$ ), COMET (LYSO), g-2( $\text{PbF}_2$ )
- fast scintillators, emission time  $\tau < 50$  ns
- $\text{BaF}_2$ , CsI emit in UV region; Cherenkov emission -  $dN/d\lambda \sim 1/\lambda^2$  - also UV
- readout requires UV-sensitive photodetectors
- $\text{BaF}_2$  has unique rate capabilities :  $\tau_{\text{fast}} < 1$  ns, 1800 photons / MeV
  - ▶ however, intensity of the slow emission component  $> 80\%$  of the total
  - ▶ at high rates, the slow component needs to be suppressed

## more on BaF<sub>2</sub> crystals



- energy resolution 2.5% at 1 GeV demonstrated (TAPS)
- light yield stable after 10 Krad

## Photodetectors for BaF<sub>2</sub> calorimeter




- Mu2e is planning to read out BaF<sub>2</sub> with large area (9x9 mm<sup>2</sup>) UV-sensitive APDs
- these APD's also have an optical band filter - solar blind
- the signal integration time - 50-100 ns
- 1 ns fast scintillator calls for a photodetector with the response time of the order of 1 ns

## Pulses from a pair of 8" MCP Al<sub>2</sub>O<sub>3</sub> plates

B. Adams, A. Elagin, R. Obaid, E. Oberla,  
M. Wetstein et al.

A. Elagin, today CPAD/Photodetectors



(Note-to-self: forward-reference Eric Oberla's single-ended readout)


6/5/2014

TIPP June 5, 2014

24



- microchannel plate-based detectors: full pulse within three nanoseconds

## LAPPD MCP's lifetime measurements



- LAPPD MCP: regular borosilicate glass , activated by atomic layer deposition (ALD)
- emission-active layer:  $\text{Al}_2\text{O}_3$  or  $\text{MgO}$ , gain - up to  $(2-3)10^7$  with  $\text{MgO}$
- remarkably, no signs of gain reduction up to  $7 \text{ C/cm}^2$  for  $V > 1.5 \text{ kV}$
- no pre-amplification needed

### Gain and Time Resolution of SL10



Albert Lehmann

Cherenkov-Workshop --- Gießen --- May 11-13, 2009


10

- photodetectors have to operate in the magnetic field
- PANDA RICH studies: Hamamatsu SL10 **gain at B=1.5T is ~ 60% from the gain at B=0**




## non-alkali UV-sensitive photocatodes

U.Schühle, J.-F.Hochedez, "Solar-Blind UV detectors", in ISSI Scientific Report SR-009, ISBN: 978-92-9221-938-3



- wide band semiconductors: UV sensitive and solar-blind simultaneously
- GaN (band gap = 3.5 eV) used in astrophysics for quite some time
- wide-band semiconductors are radiation hard, many GaN devices intended for use in radiation-harsh environment

## Opaque vs semi-transparent photocatodes



- can deposit GaN directly on MCP - opaque mode photocathode
- crystalline GaN (MBE at  $\sim 700$  C) requires sapphire substrates
- amorphous photocathodes can be deposited at much lower temperature

O.Siegmund et al, Proc. SPIE 7021, 70211B, 2008, doi:10.1117/12.790076




Figure 9. Opaque QE vs. wavelength for 500nm GaN on Alumina substrates (107062701 solid alumina substrate, 107062601 – substrate with 25 $\mu$ m holes) compared with 150nm GaN (107062001 [two thermal procedures]).





Figure 10. QDE vs. wavelength for semitransparent GaN. 150nm GaN (107062001), 100nm GaN (106071702), both on sapphire, 30nm AlGaIn, P doped up to  $2 \times 10^{19} \text{ cm}^{-3}$ .



- $QE_{opaque} \sim 30\%$  at 220 nm
- transparent mode: lower QE overall, depends on the photocathode thickness

## Readout: Pileup separation




- pileup in the calorimeters usually results in “extra energy”
- it also can result in the losses
- move towards readout base on waveform sampling, pulse shape analysis

## Digitizing 5 ns long pulses: data volumes



- waveform digitization: timing resolution @100 MeV :  $\sim (\text{time bin}) / 15\text{-}20$
- leading edge of 1 ns : need sampling rate  $\sim 3$  GHz or above
- for comparison, Mu2e calorimeter plans to use 200 MHz sampling rate
- with pulses shorter than 5 ns, can digitize a range of 10 ns instead of 100 ns per pulse
- data volume increases with occupancy, not with the sampling rate



- can match the photodetector size to the crystal size - light yield improvement
- SiPM/APD-based readout of g-2, Mu2e: ' $S_{\text{photodetector}}/S_{\text{crystal}} \sim 20\%$ '
- MCP-based photodetector can be made  $\sim 1''$  thin

## there are open questions - always

- radiation hardness: individual components don't have much to suffer from radiation
- performance: what happens when a shower tail reaches the photodetector?
- relatively new device - any long term effects ?
- LAPPD project made a low cost promise - how low \$/channel could be for 1000 channels ?

## Summary

- radiation-hard  $\text{BaF}_2$  crystals provide an excellent choice for the next generation high-rate crystal calorimeters - Mu2e is exploring this option
- MCP-based photodetectors with GaN photocathodes seem to be a natural match to the  $\text{BaF}_2$  scintillator
- combination could lead to improving the rate capabilities of intensity frontier crystal calorimeters by an order of magnitude w/o sacrificing the energy and timing resolutions